

# ASSEMBLY INSTRUCTIONS FOR LED LIGHT PANEL

**SYSTEM 1224**  
**12.2 - 1070267**

## INSTRUCTIONS FOR USE:

1. PULL DOWN ON THE BOTTOM OF OUTER BEZEL TO RELEASE, UNHOOKING IT FROM THE TOP OF THE BACK HOUSING.


2. REMOVE CLEAR PLASTIC FRONT.

3. INSERT EITHER DURATRANS FOR GRAPHIC USE, OR WHITE PLASTIC DIFFUSER FOR NON-GRAPHIC USE.

4. RESTACK CLEAR PLASTIC SHEET ON TOP OF DURATRANS OR WHITE PLASTIC DIFFUSER FROM STEP 3.

5A. REHOOK BEZEL ONTO THE BACK HOUSING BY FIRST HOOKING THE TOP SIDE OF BEZEL OVER BACK HOUSING INTO GROOVE.

5B. THEN HOOK THE BOTTOM SIDE OF BEZEL INTO GROOVES ON THE UNDERSIDE OF HOUSING.



**APPROVED**  
By *dwilliams* at 8:06 am, Sep 30, 2014



**B&N INDUSTRIES**  
650.593.4127  
WWW.BNIND.COM