



Assembly & Installation Instructions


① Insert



② Click



5.1 : POG BASIC



Basic Pog Accessory Installation

1. Insert- Pog component into Pog Insert on panel. Make sure the accessory spring is facing upward.
2. Click- You will here a snap when component is seated. If you don't hear a snap twist the Pog Faceout, or accessory, back and forth until you hear the snap of the spring.

APPROVED
By dwilliams at 9:22 am, Jul 27, 2010



B&N INDUSTRIES
650.593.4127
WWW.BNIND.COM